AMUTARINSTRUMENTS

Wood hardness tester AS-120DW

describe

Wood hardness tester is used to measure wood hardness. It is an indentation hardness tester.

characteristics

- * Adopt computer technology, digital filter technology and other advanced technology, can accurately measure The density of the material.
- * Automatic indication when the battery voltage is lower than the specified value.
- * Digital display, ignoring the difference.
- * Using the optional RS232C software and cable, can communicate with the PC computer, to achieve digital Data collection, processing, analysis and printing functions
- * With automatic shutdown function, save electricity.



parameter

Show indicator	4-bit 10 mm liquid crystal
Show around	0HD~100 HD
Test range	10HD~90 HD
Points and distinguishing rate	0.1 HD
Accuracy of measurement	≤ ±1 HD
Electrical source	2 size 7 batteries
Speaking for the parts	Temperature 0∼50°C, humidity <80%
size	162mmx6mm5x27 mm
Heavy volume	170 g (battery not included)
Standards attached	1 portable case
	1 copy of instruction manual
	Calibration block 1 piece
Optional attached parts	USB Data Cable with Software/Bluetooth Data Adapter with Software